

# Health & Safety, Use & Care, Installation Guide Front Load Washer Models:

FWMD10502GW FWMD11003BG

# **USER MANUAL**



THANK YOU FOR BUYING A WHIRLPOOL PRODUCT.



Read operator's manual

#### **INDEX**



#### **SAFETY INSTRUCTIONS**

#### IMPORTANT TO BE READ AND OBSERVED

Before using the appliance, read these safety instructions. Keep them nearby for future reference. These instructions and the appliance itself provide important safety warnings, to be observed at all times. The manufacturer declines any liability for failure to observe these safety instructions, for inappropriate use of the appliance or incorrect setting of controls.

⚠ Very young children (0-3 years) should be kept away from the appliance. Young children (3-8 years) should be kept away from the appliance unless continuously supervised. Children from 8 years old and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge can use this appliance only if they are supervised or have been given instructions on safe use and understand the hazards involved. Children must not play with the appliance. Cleaning and user maintenance must not be carried out by children without supervision.

Never open the door forcibly or use it as a step.

#### **PERMITTED USE**

⚠ CAUTION: The appliance is not intended to be operated by means of an external switching device, such as a timer, or separate remote controlled system. ⚠ This appliance is intended to be used in household and similar applications such as: staff kitchen areas in shops, offices and other working environments; farm houses; by clients in hotels, motels, bed & breakfast and other residential environments.

⚠ Do not load the machine above the maximum capacity (kg of dry cloth) indicated in the programme table.

This appliance is not for professional use. Do not use the appliance outdoors.

⚠ Do not use any solvents (e.g. turpentine, benzene), detergents containing solvents, scouring powder, glass or general purpose cleaners, or flammable fluids; do not machine wash fabrics that have been treated with solvents or flammable liquids.

#### **INSTALLATION**

⚠ The appliance must be handled and installed by two or more persons - risk of injury. Use protective gloves to unpack and install - risk of cuts.

If you want to stack a dryer on top of your washing machine, first contact our After-Sales Service or your specialist dealer to verify whether this is possible. This is only possible if the dryer is attached to the washing machine by means of appropriate stacking kit available through our After- Sales Service or your specialist dealer.

⚠ Move the appliance without lifting it by the worktop or top lid.

⚠ Installation, including water supply (if any) and electrical connections and repairs must be carried out by a qualified technician. Do not repair or replace any part of the appliance unless specifically stated in the user manual. Keep children away from the installation site. After unpacking the appliance, make sure that it has not been damaged during transport. In the event of problems, contact the dealer or your nearest After-sales Service. Once installed, packaging waste (plastic, styrofoam parts etc.) must be stored out of reach of children - risk of suffocation. The appliance must be disconnected from the power supply before any installation operation - risk of electric shock. During installation, make sure the appliance does not damage the power cable - risk of fire or electric shock. Only activate the appliance when the installation has been completed.

⚠ Do not install your appliance where it may be exposed to extreme conditions, such as: poor ventilation, temperatures below 5 °C or above 35 °C. ⚠ When installing the appliance make sure that the four feet are stable and resting on the floor, adjusting them as required, and check that the appliance is perfectly to level using a spirit level.

⚠ If the appliance is being installed on wood or "floating" floors (certain parquet and laminate materials), secure a 60 x 60 x 3 cm (at least) sheet of plywood to the floor then place the appliance on top of this.

⚠ Connect the water inlet hose(s) to the water supply in accordance with the regulations of your local water company.

⚠ For cold fill only models: do not connect to the hot water supply.

⚠ For models with hot fill: the hot water inlet temperature must not exceed 50 °C.

⚠ The washing machine is fitted with transport bolts to prevent any possible damage to the interior during transport. Before using the machine, it is imperative that the transport bolts are removed. After their removal, cover the openings with the 4 enclosed plastic caps.



△ After installation of the device, wait a few hours before starting it so that it acclimates to the environmental conditions of the room.

⚠ Make sure that the ventilation openings in the base of your washing machine (if available on your model) are not obstructed by a carpet or other material.

⚠ Use only new hoses to connect the appliance to the water supply. The old hose-sets should not be reused.

⚠ The supply water pressure must be in the 0.03-1 MPa range.

#### **ELECTRICAL WARNINGS**

⚠ It must be possible to disconnect the appliance from the power supply by unplugging it if plug is accessible, or by a multi-pole switch installed upstream of the socket in accordance with the wiring rules and the appliance must be earthed in conformity with national electrical safety standards. ⚠ Do not use extension leads, multiple sockets or adapters. The electrical components must not be accessible to the user after installation. Do not use the appliance when you are wet or barefoot. Do not operate this appliance if it has a damaged power cable or plug, if it is not working properly, or if it has been damaged or dropped.

(1) If the supply cord is damaged, it must be replaced with an identical one by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard - risk of electric shock.

#### **CLEANING AND MAINTENANCE**

⚠ WARNING: Ensure that the appliance is switched off and disconnected from the power supply before performing any maintenance operation; never use steam cleaning equipment - risk of electric shock.

#### **DISPOSAL OF PACKAGING MATERIALS**

The packaging material is 100% recyclable and is marked with the recycle symbol .

The various parts of the packaging must therefore be disposed of responsibly and in full compliance with local authority regulations governing waste disposal.

#### **DISPOSAL OF HOUSEHOLD APPLIANCES**

This appliance is manufactured with recyclable or reusable materials. Dispose of it in accordance with local waste disposal regulations. For further information on the treatment, recovery and recycling of household electrical appliances, contact your local authority, the collection service for household waste or the store where you purchased the appliance. By ensuring this product is disposed of correctly, you will help prevent negative consequences for the environment and human health.

The symbol on the product or on the accompanying documentation indicates that it should not be treated as domestic waste but must be taken to an appropriate collection center for the recycling of electrical and electronic equipment

# INSTALLATION INSTRUCTIONS Transport

Transport must be handled by two persons. Two persons should respectively stand on two sides of the washing machine and hold with both hands to transport the washing machine.



#### Placing the washing machine correctly

The washing machine must be installed on firm, flat and slip-proof ground. Do not place the washing machine on carpeted or wood covered floor. It is forbidden to place the washing machine on a ground platform and rack.

The washing machine must keep a minimum distance of 10 cm away from the wall or the hard reflector on three sides.








1. On sloping ground

2. On ground platform and rack 3. On uneven ground

#### Removing transport bolts and base protector

To protect the washing machine during transport, the internal structure of the washing machine is fastened with four transport bolts. All the transport bolts should be removed before use. (If the bolts are not removed, the washing machine will vibrate vigorously, generate loud noises and function improperly during spinning.)

- 1.Loosen the transport bolts (four pieces) with a wrench.
- 2. Shake the bolts left and right to pull them out.
- 3. Align the bolt covers with the original bolt holes and press until they fit.
- Please keep the transport bolts safe. They are necessary to make a move.
- Do remove the base protector before use, as shown in the figure, or the washing machine will function improperly.





#### Level adjustment

If installed on an uneven place, the washing machine will generate abnormal noises or vibrations or function abnormally when in use.


- 1. The feet of the washing machine (the four feet are all adjustable) can be adjusted by the following method:
- 1. Loosen clockwise the locking nuts of the washing machine feet with the wrench and rotate the feet to adjust the height so as to make the washing machine level.
- 2. When allowed by conditions, use a level meter to check the adjusted state of the washing machine and make calibration when necessary.

Note: all four feet must reliably touch the ground and stand on the ground firmly.



3. Tighten the locking nuts counterclockwise with the wrench to lock the nuts to the bottom of the case.

4. After adjustment, press the diagonal corners of the top cover of the washing machine by a proper force with two hands to confirm that the washing machine is stable.



#### **Choosing water tap**

Water tap type: (The opening of the water tap should be flat.)

Type A: most suitable type

Type B: the water tap length must be greater than 16 mm, or the universal joint cannot be installed.

Type C: Water may leak from the position as shown in the figure.

#### **CĂUTIONS:**

- Do not connect to a hot water source of over 50°C.
- If the water tap used is not suitable, replace with a suitable one.



#### Connecting the inlet hose

Note: The new inlet hose in the attachment must be used. The old inlet hose cannot be repeatedly used.

#### How to attach the inlet hose

1.Loosen the four screws and slide the top of the inlet hose Hose Joint (section A in the figure) onto the faucet. Then, securely tighten the four screws provided with the inlet hose Hose Joint by using a screwdriver to secure the top of the joint to the faucet.

2.Remove the CAUTION label from the inlet hose Hose Joint.
3.Turn the male coupler on the joint (section B in the figure) clockwise to attach it securely to the top of the joint (section A in the figure).




#### **CAUTIONS:**

If outer diameter of faucet is larger than caliber of the Joint Ring, loosen the four screws and remove the Joint Ring from the inlet hose Hose Joint.

#### **Connecting Water Inlet Hose to the Washer**

Turn the nut clockwise till the nut is tight while holding the hose.

Turn the nut counterclockwise after turning the faucet off if you want to detach the water inlet hose.




#### **Connecting the Drain Hose**

1. When the machine is not in use, put drain hose at the back of machine (figure 1).

2. When in operations, put drain hose into drainage duct (figure 2); you can also put end of drain hose into sewer, leaving space between end of drain hose and sewer elbow to avoid difficulty in draining water out of washing machine.

3.Clean filter in pump periodically to keep the washing machine working normally.

Note: Do not take off drain hose to avoid drainage problems.




#### **Specification Sheet**

Model name	FWMD10502GW	FWMD11003BG		
Mashing capacity	10.5kg	11kg		
Spinning capacity	10.5kg	11kg		
Rated voltage	220~240V/50Hz	230V/60Hz		
Rated power	1800W			
Washing noise	49dB			
Spinning noise	68dB			
Water pressure	0.03~1.0MPa			
Product dimension	599mm*643mm*850mm			



#### **PRODUCT DESCRIPTION**




- 1. Worktop
- 2. Detergent dispenser
- 3. Control panel
- 4. Door handle
- 5. Door
- 6. Water filter behind pump cover
- 7. Pump cover
- 8. Adjustable feet (4)


#### **DETERGENT DISPENSER**

# Laundry sanitizer compartment

The sanitizing liquid is placed in this compartment. It is recommended to use the sanitizing liquid with an ingredient of parachlormetaxylenol. To prevent damage to clothes, the highly concentrated sanitizing liquid should be added according to its instructions.



- Fabric softener will be automatically injected into the drum during the final rinse.
- Consumer should follow the softener instructions.



#### Main wash compartment


- Detergent for the main wash. For liquid detergent or powder detergent.
- Detergent which is difficult to dissolve, such as powder-shaped soap, should be fully dissolved in advance and then poured into this compartment.
- Special detergent for the front loading washing machine should be used.
- Follow the dosage recommendation. It optimizes the cleaning result, it avoids irritating residues of surplus detergent in your laundry and it saves money by avoiding waste of surplus detergent.
- Detergent should be used according manufacturer's instructions and the type, color, water temperature and degree of stain of the laundry.

#### **TECHNICAL DATA FOR WATER CONNECTION**

Water connection	
Water supply	Cold
Minimum water supply pressure	30kPa (0.3bar)
Maximum water supply pressure	1000 kPa (10 bar)



#### **CONTROL PANEL**



- 1."ON/OFF" button
- 2.Programme area
- 3. Option button
- **4.** "Start/Pause" button ▷ ■
- 5. QUICK STAIN option
- 6. HYBRID option

#### **CONTROL PANEL**

- Interactive knob can be rotated, pressed and display functions. The display panel can show programmes, time remaining, parameters, options, status of operation, etc.
- Rotate the knob to choose desired wash programmes, press the knob to start; when a programme is running, the knob will has a function of 'start/pause'.
- when the machine is in standby, long press the knob for 3 seconds will initiate the Auto start programme.

#### **PROGRAMME AREA**

- When power on, the default programme is "Mixed", rotate the knob to choose desired programme, and the chosen programme will be lighted, other programmes' light will dim.
- When a programme has been running consecutively for more than 3 times, then the programme will become default when power on the next time.

# Rotate to choose, press to select/start Additional functions for current programme (lit on means set) Remaining time & animation for current programme (Wash temperature, Rinse times, Spin speed) Rotate to choose, press to select/start Hybrid indicator Child lock indicator Door lock indicator

#### **PROGRAMMES**

For choosing the appropriate programme for your kind of laundry, always respect the instructions on the care labels of the laundry. The value given in the tub symbol is the maximum temperature possible for washing the garment

#### MIXED

- For washing lightly to normally soiled resilient garments in cotton, linen, synthetic fibres and mixed fibres.
- When choosing this programme, you can change the temperature, speed and rinse times.

#### QUICK

- For quick washing of small load or lightly soiled garments. For best result, do not exceed max kg laundry.
- When choosing this programme, you can change the temperature, speed and rinse times.

#### **GENTLE**

- For washing particularly delicate garments. Preferably turn garments inside out before washing.
- When choosing this programme, you can adjust the temperature, speed and rinse times.

#### **SPIN**

- Spins the load then empties the water.
- When choosing this programme, you can adjust the speed.

#### **AIR REFRESH**

- This programme refreshes garments by removing bad odours and relaxing the fibres for easy ironing.
- When choosing this programme, you cannot change the temperature, speed and rinse times.

#### WOOL

- Wool garments can be washed using programme "Wool" (Machine washable). For best result, use special detergents and do not exceed maximum kg declaration of laundry for this programme.
- When choosing this programme, you can adjust the temperature, speed and rinse times.

#### ALLERGY CARE

- Effectively remove allergens such as dust mites, pollen and fur.
- When choosing this programme, you can change the temperature, speed and rinse times.

#### **SANITIZE WASH**

- This programme requires you to add laundry sanitizer into its dedicated compartment, which can effectively reduce and prevent bacterial reproduction.
- When choosing this programme, you can adjust the temperature, speed and rinse times.

#### **DRUM CLEAN**

- For drum cleaning only, using high temperature and oxycare to sterilize the drum to effectively remove dirt and bacteria.
- When choosing this programme, you cannot adjust the temperature, speed and the rinse times.



#### **ECO COTTON**

- For washing normally soiled cotton garments. At 60°C, this is the standard cotton programme and the most efficient in terms of water and energy consumption.
- When choosing this programme, you can change the temperature and speed.

#### **RINSE+SPIN**

- Used to rinse and spin the load.
- When choosing this programme, you can change the speed and rinse times.

#### **BEDDING**

- For washing big items like home textile.
- When choosing this programme, you can change the temperature, speed and rinse times.

#### **OPTIONS**

#### TEMP 1

- Every programme has a predefined temperature. If you want to change the temperature, press the "TEMP" button. The value appears on the display.
- Long pressing for 3s to select the child lock function.

#### RAPID

• Enables quicker washing. The cycle duration is reduced based on the programme selected.

#### STAIN \*

Power on, rotate the knob to select the right programme, then press 'Stain' button to enables stain wash function. This function helps to remove all kinds of stains for daily clothes (for selected programmes). Pre-treatment is recommended for stubborn stains. When set stain function successfully, the icon of ⊀ is lit.

#### **QUICK STAIN**

•Power on, rotate the knob to select the right programme, then press"QUICK STAIN" button to select stain types, which includes red wine, oil stain, makeup stain. This function is to treat specific stain quicker for daily clothes.

When set special stain function successfully, the icon of "" is lit, and the icon of corresponding stain is lit too.

Stain type	Introduction of special stain function.		
Red wine	To treat wine stain on daily clothes.		
Oil stain 🚭	To treat oil stain on daily clothes.		
Makeup A stain	To treat makeup stain on daily clothes.		

#### Note:

The appliances adjust the average washing temperature to ensure the wash programme is specifically adapted to each type of stain. This ensures stains are treated in the best possible way.

#### RINSE

- By selecting this option, the efficiency of the rinse is increased and optimal detergent removal is guaranteed.
- It is particularly useful for sensitive skin.

#### **SPEED**

• Every programme has a predefined spin speed. If you want to change the spin speed, press the "Speed" button. The value appears on the display.

#### **DELAY**

 Power on, select a programme and desired functions, press "Delay" button to set an appointment time.

Steps to set Delay time

- 1.Press "Delay" button, the time will be changed in order;
- 2. Long press "Delay" button, the time will be changed continuously:
- 3. After setting delay time, press knob or press 'Start/Pause' button to start delay function.
- 4. Press power button to exit delay phase.
- 5. The maximum Delay time is 24H, the set delay time is the finish time.
- 6. The ending time may differ when setting delay due to the difference of water pressure, load, water temperature and so on.

When delay function successfully, the icon of is lit.



#### **HYBRID STEAM**

- Select desired programme, and press "HYBRID" button to choose between Ozone + steam, Ozone only, or Steam only.
- Press "Start/ Pause" button or press knob to start programme.

Mode	For compatible wash programmes	For air refresh programme
Ozone + steam	Steam and ozone work during the operation to care and sterilize clothes. When selecting this option, there will be an ozone operation phase followed by steam to block proliferation of unpleasant odours caused by bacteria. After the operations, the machine will generates steam periodically and perform slow drum rotations to prevent crease formed. This option cycle starts at the end of washing programme and continue for maximum 6 hours; it can be interrupt at any time by pressing 'Start/pause' button or press the knob. Wait for few seconds before opening the door.	and sterilize clothes. When selecting this option, there will be an ozone operation phase followed by steam to block proliferation of unpleasant odours caused by bacteria. During the steam phase, the machine will perform slow drum rotations to prevent crease formed.
Ozone	Ozone works during the operation to sterilize clothes, the drum will rotate but there is no 6 hours steam.	Ozone works during the operation to sterilize clothes. In this mode, the drum will not rotate and there is no 6 hours steam.
steam $\langle \cdot \rangle$		Steam works during the operation to care and refresh clothes. In this mode, the drum will rotate but there is no 6 hours steam.

<sup>■</sup> The mode selected will be lit. For ozone + steam mode, the icon of HYBRID () is lit.

Suggestion tip: Selecting Hybrid steam will invoice ozone + steam operation, is composite function, Ensure water tap is turned on.

#### **FUNCTIONS**

#### ON/OFF

- To switch on the washing machine: press the button.
- To switch off the washing machine after programme end: long press the (1) button until the lights go off.
- To save energy, the washer will be automatically switch off approximately 10 mins after programme end.

#### START/PAUSE

• To start the programme after you have finished your settings. Press this button once to pause it after programme has started. To continue, press again to resume the operation.

#### **AUTO START**

- Long press 3s the knob will activate Auto Start programme from shutdown mode. The max. wash load is 7kg. You can only adjust speed and rinse times.
- Not recommended for wool or silk garments.

#### **CHILD LOCK**

- You can activate the child lock function to prevent unintentional changes to programmes, especially with children near the machine. Both the door and programme buttons will be locked automatically.
- Turn on machine and press "TEMP" button for 3 seconds till the buzzer sounds. The child lock function is activated. Repeat steps to deactivate.

#### **ADD CLOTHES FUNCTION**

- As long as a wash programme is running, the door remains locked. To open the door while a programme is in progress, press the "Start/Pause" button. Provided the water level and/or temperature is/are not too high, you can open the door. For example to add/remove laundry.
- Press the "Start/Pause" button again to continue the programme.
- Forcing the door to open may cause parts damage or injury.



#### **PROGRAMME SELECTION**

 After the washing machine is powered on, you can select the desired wash programme depending on the load and stain level.

#### **POWER SAVING FUNCTION**

• 2 minutes after the machine has started (non-pause), the control panel will enter into power saving function. Touch any button except power button to wake up the UI.

#### **ADJUSTABLE PARAMETERS**

- When running a programme, you can still change some settings without the need to pause or restart the programme.
- Parameters that can be adjusted are rinse times, spin speed and add Hybrid option.
- You can only change the parameters before start of the operation.

#### PROGRAMME CHART

	Temperatures		Max spin (rpm)	Max wash load (kg)		Programme		Ι. Ι	Ī., . I		Quick	Detergents & Additives			
Programme	Setting	Range	Rinse	10.5/11kg	10.5	11	time	Rapid	Delay	Stain	Hybrid	stain	Laundry sanitizer	Main wash	Softener
Mixed	30℃	<b>∰</b> -60°C	default: 2 range: 0-6	1400	7	7	1:02	•	•	•	•	•	0	•	•
Quick	*	<b>╬</b> -30℃	default: 1 range: 0-4	1000	1	1	0:15	0	•	0	•	0	0	•	•
Allergy care	60℃	60-90℃	default: 3 range: 0-6	1400	4	4	2:03	•	•	0	•	0	0	•	•
Spin	-	-	-	1400	10.5	11	0:11	•	•	0	0	0	0	0	0
Rinse + spin	-	-	default: 1 range: 0-6	1400	10.5	11	0:20	0	•	0	•	0	0	•	•
Sanitize wash	30℃	<b>∰</b> -90℃	default: 2 range: 2-6	1400	8	8	1:32	•	•	•	•	•	•	•	•
Gentle	40℃	<b>∰</b> -40°C	default: 3 range: 0-6	1000	4	4	1:31	•	•	0	0	•	0	•	•
Wool	40℃	<b>╬</b> -40℃	default: 2 range: 0-6	800	1	1	1:09	0	•	0	0	0	0	•	•
Air refresh	-	-	default: 0	-	1	1	0:40	0	•	0	•	0	0	0	0
Bedding	30℃	<b>∰</b> -60℃	default: 2 range: 0-6	1200	7	7	1:22	•	•	•	•	•	0	•	•
Eco cotton	60℃	<b>∰</b> -60℃	default: 2	1400	10.5	11	3:50	0	•	0	0	0	0	•	•
Drum clean	90℃	-	default: 1	800	-	-	3:04	0	•	0	0	0	0	0	0

• : Compatible options to add on to wash programmes

#### Singapore (water label)

**Eco cotton** This is the recommended programme for normally soiled clothes at rated load capacity. Test wash cycles in compliance with regulations **IEC 60456**. These are the reference programmes for the water label and energy label. Set this wash cycle with a temperature of 60°C. It is the most efficient programme in terms of water and energy consumption. The actual water temperature may differ from the declared one.

#### Hong Kong (water label and energy label)

Eco cotton ☐ This is the recommended programme at rated load capacity. Test wash cycles in compliance with regulations IEC 60456. These are the reference programmes for the water label and energy label. Set this wash cycle with a temperature of 60°C. It is the most efficient programme in terms of water and energy consumption. The actual water temperature may differ from the declared one.

#### **For all Test Institutes**

Long wash cycle for cottons: set wash cycle Eco cotton with a temperature of  $60^{\circ}$ C.

This data may differ in your home due to changing conditions in inlet water temperature, water pressure etc. Approximate programme duration values refer to the default setting of the programmes, without options.

#### For all Test Institutes

Long wash cycle for cottons: set wash cycle Eco cotton with a temperature of  $60^{\circ}$ C.

This data may differ in your home due to changing conditions in inlet water temperature, water pressure etc. Approximate programme duration values refer to the default setting of the programmes, without options.

#### **DOOR**

To open the door, pull the handle.



To close the door, hold the handle and push so that you can hear it click shut.






#### **HOW TO USE THE APPLIANCE**

#### **ACCESSORIES**

Contact our After-Sales Service to check if the following accessories are available for your washing machine (and dryer) model



#### **DAILY USE**

#### PREPARING THE LAUNDRY



#### **Empty pockets**

- Coins, paper clips, etc. could damage the load and the washing machine components.
- Tissues will break down during the wash cycle, and the fragments will have to be subsequently removed by hand.



#### Close all zippers, buttons, and hooks. Tie all ribbons or belts



Insert the smaller garments (e.g. nylon hosiery, belts, etc.) and garments with hooks (e.g. braziers) into a fabric bag or a pillowcase with a zipper. Remove any rings from curtains, or else place the curtains inside a fabric bag together with the rings.

#### **HOW TO USE THE WASHING MACHINE**

#### Load laundry



Open the door and load the laundry. Load the articles one at a time loosely into the drum, without overfilling. Observe the load sizes given in the

"PROGRAMME CHART" table. Overloading the machine will result in unsatisfactory washing results and creased laundry

#### 2. Close door





Make sure that no laundry gets stuck between door glass and rubber seal. Close the door so that you can hear it click shut.

#### 3. Open water tap

Make sure that the washing machine is connected to the water mains. Open the water tap.

#### Switch on washing machine

Press the "ON/OFF" . The programme setting which you must frequently will appear on the control panel.

#### 4. Set the desired programme

Select the required programme. The display will show the duration of the cycle.

Adjust the temperature and/or spin speed settings if needed with the relative buttons.

#### Fabric type / Symbol on the wash label

- Cottons, mixed fibres, easy care/synthetics, wool, handwash items.
- Colour
  - Separate coloured and white items. Wash new coloured articles separately.
- - Wash items of different sizes in the same wash load, to improve washing efficiency and distribution of the articles in the drum.
- **Delicates** Wash delicate items separately; they require gentle treatment.

#### Change temperature, if needed

Press "TEMP" button temperature will increase step by step to maximum. Press "TEMP" again, "--" display on screen, to show room temperature. Continue to press "TEMP" "TEMP" button to increase temperature continuously.

#### Change spin speed, if needed

Press "SPEED" button once, default speed display on screen. Continue to press "SPEED" button, speed increasing to maximum. Press "SPEED" again, minimum speed display on screen. Continue to press "SPEED" button to increase speed continuously.

#### Change rinse times, if needed

Press "RINSE" button once, default rinse time display on screen. Continue to press "RINSE" button, rinse time increasing to maximum. Press "RINSE" again, nothing display on screen, to show rinse time zero. Continue to press "RINSE" button to increase rinse time continuously.

#### Change the cycle time, if needed

Press "Rapid" for quicker washing, The cycle duration is reduced based on programme selected.

#### Select options, if needed

Press the button to select the option. The programme parameter will be displayed on the screen.

/!\ If the selected option is incompatible with the programme set, the incompatibility will be signalled by a buzzer (2 beeps)



#### **EN**

#### 5. Add detergent

Pull out the detergent dispenser and add detergent (and additives/softener) into the relative compartments as described in section "DETERGENT DISPENSER". Observe the dosing recommendations on the detergent pack.

Correct dosing of detergent / additives is important, because:

- it optimizes the cleaning result
- it avoids irritating residues of surplus detergent in your laundry
- it saves money by avoiding waste of surplus detergent
- it protects the washing machine by avoiding calcification of components
- it respects the environment by avoiding unnecessary environmental burden.

#### 6. Delaying the ending time of a programme

 When press "DELAY" button you can set the end time of the programme.

#### 7. Start programme

- Press the "Start/Pause" \( \subseteq \text{\mathbb{M}} \). the door will locked automatically.
- To avoid overflow, do not open the detergent dispenser during a running programme.
- The remaining programme duration which is indicated on the display can vary. Factors like unbalance in the wash load, or foam formation, can have an effect on the programme duration.

### 8. Change the settings of a running programme, if needed

You can still change the settings while a programme is running. The changes will be applied, provided the respective programme phase has not start yet.

If you have changed the programme, do not add detergent for the new programme.

To prevent that a running programme is changed by accident (for instance by children), use the "Key lock" =—O (see section "FUNCTIONS").

# Pause a running programme and open the door, if needed

- Press "Start/Pause" \( \sum \) It to pause a running programme.
- Provided water level is not too high, water temperature below 50°C. the ☐ lights off, you can open the door, for example to add more laundry, or to remove laundry which was loaded by mistake.
- Press "Start/Pause" \( \subseteq \text{It to proceed with the programme} \).

#### 9. Cancelling a running programme, if needed

- Press and hold the "ON/OFF" () button until the washing machine stops.
- If the water level and temperature are low enough, the door unlocks and may be opened.
- The door remains locked if there is water in the drum. To unlock the door, switch the washing machine on, select the spin programme and turn the spin option off by setting the spin speed to "--".
- The water is emptied and the door unlocks at the end of the programme.

#### 10. Switch off the washing machine after programme End

- At the end of the cycle, after the washing cycle ends, in the default state, the washing machine buzzes to prompt user. If the buzzer prompt is not required the setting can be canceled. (press "ON/OFF" button, after confirming that the machine is powered on, long press "Start/Pause" button, when you hear the prompt tone for the second time, the buzzer prompt is canceled.)
- The door can only be opened when the 🕤 lights off.
- Check that the door locked symbol is lit, then open the door and take out the laundry.
- Press "ON/OFF" (1) to switch the washing machine off.

To save energy, if the washing machine is not switched off manually with the button, it turns off automatically approximately 10 minutes after the end of the programme. Leave the door ajar to let the interior of the washing machine dry.



#### **INDICATORS**

=0	Child Lock	This indicator will light up: Child lock function activated, all buttons (except for power button) locked.
<u>(</u>	Delay end	This indicator will light up: Delay end function activated.
Î	Door lock	This indicator will light up: 1. Machine is running a programme. 2. High temperature in drum. 3. High water level.
0	Hybrid	This indicator will light up: When the hybrid function is set.
*	Stain	This indicator will light up: 1. When the quick stain function is set. 2. When the stain function is set.
6 sense	Auto start	This indicator will light up: When auto start cycle is running.

#### **HINTS AND TIPS**

#### **RULES FOR SEPARATING LAUNDRY**

- Fabric type / indications on label (cotton, mixed fibres, synthetic, wool, handwash items)
- Colour (separate coloured garments from whites, wash new coloured items separately)
- Size (wash items of different sizes in the same load to improve washing efficacy and weight distribution in the drum)
- Delicates (place small items such as nylon stockings and garments with clasps such as braziers in a laundry bag or in a pillow case with a zip).

#### WASH SYMBOLS ON GARMENT LABELS

The value given in the tub symbol is the maximum temperature possible for washing the garment.

n
ĺ

	Reduced	mechanical	action
--	---------	------------	--------

- Much reduced mechanical action
- Hand wash only
- 127 Do not wash

#### **CLEAN THE WATER FILTER REGULARLY**

• This is needed to prevent the filter from blocking and preventing the water from draining correctly.

# SAVING ENERGY AND PROTECTING THE ENVIRONMENT

- Keeping within the load limits indicated in the "PROGRAMME CHART" will optimise energy, water and detergent consumption and reduce washing times.
- Do not exceed the detergent quantities recommended by the detergent manufacturer.
- Save energy by using a 60 °C instead of a 90 °C wash programme, or by using a 40 °C instead of a 60 °C wash programme. We recommend using "Eco Cotton" programme, which is longer, but uses less energy.
- To save energy and time when washing, select highest spin speed available for the programme to reduce the residual water remaining in the garments at the end of the wash cycle.
- Pretreat any stains with an appropriate stain remover, or else dampen any dried-on stains with water prior to washing, as this will reduce the need to use a high temperature watch programme.
- Quick programme applicable to quick washing of a small load with lightly soiled.



#### **CLEANING & MAINTENANCE**

For any cleaning and maintenance, switch off and unplug the washing machine. Do not use flammable fluids to clean the washing machine.


#### **CLEANING THE OUTSIDE OF THE WASHING MACHINE**

Use a soft damp cloth to clean the outer parts of the washing machine.

Do not use glass or general purpose cleaners, scouring powder or similar to clean the control panel – these substances might damage the printing.

#### **CHECKING THE WATER SUPPLY HOSE**

Check the inlet hose regularly for brittleness and cracks. If damaged, replace it by a new hose available through our After-Sales Service or your specialist dealer. Depending on the hose type:



If the inlet hose has a transparent coating, periodically check if the colour intensifies locally. If yes, the hose may have a leak and should be replaced.



#### **CLEANING THE MESH FILTERS IN THE WATER SUPPLY HOSE**

1. Close water tap and unscrew the inlet hose.



2. Clean the mesh filter at the hose's end carefully with a fine brush.



**3.** Now unscrew the inlet hose on the back of the washing machine by hand. Pull out the mesh filter from the valve on the back of the washing machine with pliers and carefully clean it.




**4.** Insert the mesh filter again. Connect the inlet hose to water tap and washing machine again. Do not use a tool to connect the inlet hose. Open the water tap and check that all connections are tight.




#### **CLEANING THE DETERGENT DISPENSER**


1. Remove the detergent dispenser by pressing on the release button and at the same time pulling out the detergent dispenser.



2. Remove the insert from the softener compartment.




**3.** Clean all parts under running water, removing all detergent or softener residues.



**4.** Wipe the parts dry with a soft cloth.



**5.** Reinstall the detergent dispenser and push it back into the detergent compartment.





#### **CLEANING THE WATER FILTER / DRAINING RESIDUAL WATER**

Switch off and unplug the washing machine before cleaning the water filter or draining residual water. If you used a hot wash programme, wait until the water has cooled down before draining any water. Clean the water filter regularly, to avoid that the water cannot drain after the wash due to obstruction of the filter. If the water cannot drain, the display indicates that the water filter may be clogged.

#### Cleaning the drain pump filter / draining residual water

- 1. Power Off and unplug the washing machine from the electrical outlet.
- 2. Gently press the top area of the filter cover to open.



- 3. Place a container close to the pump to collect any spillage.
- 4. Stretch the "emergency drain hose" to the container.



5. When the container is full with water, plug the stopper to the hose end and empty the container. Repeat this procedure until no more water flows out. Afterwards firmly close the emergency drain hose with the stopper and reinsert the hose in the washing machine's base.



6 .Remove filter: Lay a cotton cloth beneath the drain pump filter, which can absorb a small amount of water . Then remove the drain pump filter by turning it out anticlockwise .





- 7. Clean the drain pump filter: remove residues in the filter and clean it under running water .
- 8. Insert the drain pump filter: Reinsert the drain pump filter again by turning it in clockwise direction. Make sure to turn it in as far as it goes; the filter handle must be in vertical position. To test water tightness of the drain pump filter, you can pour about 1 liter of water into the detergent dispenser.



#### **TROUBLESHOOTING**

The washing dryer machine may sometimes not work properly for certain reasons. Before calling the Support Centre, it is recommended to check to see if the problem can be easily resolved using the following list.

Anomalies	Possible causes / Solution
The washer does not turn on.	The plug is not inserted into the electrical outlet, or not enough to make contact. There has been a power failure. Press the ON/OFF button to reset programme. The door is not fully closed.
The wash cycle does not start.	The ON/OFF button has not been pressed. The START/PAUSE button has not been pressed. The water tap is not open. A start delay has been set.
The washer does not fill with water.	The water intake hose is not connected to the tap. The hose is bent. The water tap is not open. The mains water supply has been shut off. There is not enough pressure.
The washer loads and drains water continuously.	<ul> <li>The START/PAUSE button has not been pressed.</li> <li>The drain hose has not been installed at 120 cm from the ground.</li> <li>The end of the drain hose is immersed in water.</li> <li>The drain connector on the wall does not have an air vent.</li> <li>If the problem persists after having performed these checks, close the water tap, shut off the washer dryer, and call the Support Centre. If the dwelling is located on one of the uppermost floors of a building, a siphon effect can sometimes occur, thus causing the washer to load and drain water continuously. Special anti-siphon valves are available on the market to prevent these types of problems.</li> </ul>
The washer does not drain or does not spin.	The programme does not include the draining function: with certain programmes it must be activated manually. The drain hose is bent. The drain line is obstructed.
The washer vibrates excessively during the spin cycle	At the time of installation, the drum was not properly unlocked.     The washer is not level.     The washer is squeezed between furniture and the wall.
The washer leaks water.	The water intake hose has not been tightened properly. Please check your hose regularly and in case of any damage or leakage have it replaced. The detergent dispenser is clogged. The drain hose has not been properly fastened.
The display shows an error code.	Shut off the machine, disconnect the plug from the outlet, and wait about 1 minute before turning it back on. If the problem persists, call the Support Centre.
Too much foam is formed.	The detergent is not compatible with the washer (it must bear the wording "for washing machines", " for hand washing and washing machines", or something similar).  The dosage was excessive.
Abnormal sound during spin	The power cord or other objects touch the cabinet. Transport bolts have not been removed. Foreign objects such as coins or hairpins are in the drum.



Fault code	Description	Possible causes	Solution
No display	out of operation	<ul> <li>Whether the outlet have electricity</li> <li>Whether the plug is plugged in power cut or not</li> <li>Whether there is a power failure</li> <li>Whether the fuse has blown in the mains plug</li> </ul>	
FBE	No water	<ul> <li>Tap turn on/off?</li> <li>Whether the water inlet hose is frozen</li> <li>Whether the mesh filter is clogged</li> <li>Water stopped or not</li> </ul>	Press the "Start/ Pause" button
F9E1	undrained	<ul> <li>Ensure the drain pipe in the right place</li> <li>Drain height too high or not</li> <li>Whether the drain hose is blocked</li> <li>Ensure the drain-pipe length</li> </ul>	Press "ON/OFF" Button
Н	Door can't be opened	<ul><li>Make sure don't use hot water</li><li>The water temperature or water level is high when washing</li></ul>	Automatic unlocking Until the temperature drops to safety
UH	Door not closed		Close the door, until the "locked" light on, confirm it then press "Start/Pause"to reoperation
Other code	Alarm		Press "Start/Pause" to reoperation, If still can't solve the problem, please contact the service center.



#### **AFTER-SALES SERVICE**


#### **BEFORE CALLING THE AFTER-SALES SERVICE**

- **1.** See if you can solve the problem by yourself with the help of the suggestions given in the **TROUBLESHOOTING**
- **2.** Switch the appliance off and back on again to see if the fault persists.

# IF AFTER THE ABOVE CHECKS THE FAULT STILL OCCURS, GET IN TOUCH WITH THE NEAREST AFTER-SALES SERVICE

When contacting our Client After-sales service, always specify:

- a brief description of the fault;
- the type and exact model of the appliance;



- your full address;
- your telephone number.

If any repairs are required, please contact an authorised aftersales service (to guarantee that original spare parts will be used and repairs carried out correctly).



# Register your product online

For Singapore Warranty, please scan QR code or visit below website:



https://www.whirlpool.com.sg/warranty-registration.php

#### For Hong Kong Warranty

Save the planet and register your product warranty online! Enjoy extra 1-month free warranty upon online registration.



https://rebrand.ly/WPwarranty



