


# EN - AWE 7085 N

Max. Load: 7 kg | Max. Spin Speed: 850 rpm

## PROGRAMME CHART



- A. Programme selector
- B. Programme sequence indicator
- C. "Variable spin" button
- D. "Start(Pause)" button
- E. "Reset" button
- F. "Lid open" indication



- This washing machine is equipped with automatic safety functions which detect and diagnose faults at an early stage and react appropriately:
- G. "Service" indication
- H. "Water tap closed" indication
- I. "Clean pump" indication

Programme	Care Labels	Suggested Load kg	Type of wash / Notes <i>- for temperature selection, respect the manufacturer's recommendations on the care label</i>	Detergents and Additives			Special options					Max. Spin Speed rpm
				Pre-wash	Main wash	Softener	Cold wash	Pre-wash	Rapid	Intensive rinse	Rinse hold	
<b>Cotton / Antibacterial</b> 40 - 60 - 95°C		7.0	Normally to heavily soiled bed linen, table linen, towels and garments made of cotton and/or linen. <i>Selecting "Cotton 95", this programme eliminates bacteria, ensuring sanitization of your laundry. The bacteria removal efficiency has been tested following a similar methodology to the NF EN 13697 standard of Nov. 2001.</i>	*	Yes	*	*	*	*	*	*	max.
<b>Synthetics</b> 30 - 40 - 60°C		3.0	Normally soiled blouses, shirts, overalls etc. made of polyester (Diolen, Trevira), polyamide (Perlon, Nylon).	*	Yes	*	*	*	*	*	*	max.
<b>Delicates</b> 30 - 40°C		1.5	Curtains and delicate clothing, dresses, skirts, shirts and blouses.	*	Yes	*	*	*	-	-	*	max.
<b>Daily load</b> 40°C		3.0	Slightly to normally soiled textiles made of cotton and/or synthetics.	-	Yes	*	*	-	-	*	*	max.
<b>Speed 15'</b> 30°C		3.0	Refreshed briefly worn outer clothing made of cotton, artificial fibers and blends with cotton. Use lowest recommended detergent amount.	-	Yes	*	*	-	-	-	*	max.
<b>Wool/Handwash</b> Cold - 40°C		1.0	Woollens, labelled with the Woolmark and identified as machine washable, as well as textiles made of silk (keep to care label!), linen, wool and viscose marked as handwashable.	-	Yes	*	*	-	-	-	*	max.
<b>eCotton</b> 40 - 60°C		7.0	Normally soiled cotton laundry. <i>At 40°C and 60°C standard cotton programme and most favourable programme in terms of combined water and energy consumption for washing cotton laundry. - Reference programme for the Energy Label.</i>	-	Yes	*	-	-	-	*	*	max.
Rinse & Spin	-	7.0	<i>Same as the last rinse and the final spin in the "Cotton" programme.</i>	-	-	*	-	-	-	*	*	max.
Spin	-	7.0	<i>In this programme spinning is intensive. Same as the spin cycle in the "Cotton" programme.</i>	-	-	-	-	-	-	-	*	max.
Gentle spin	-	1.0	<i>Separate gentle spin programme. Suitable for delicate laundry.</i>	-	-	-	-	-	-	-	*	max.
Drain	-	-	<i>Drain only - no spinning. Alternative method of terminating programme after "Rinse hold".</i>	-	-	-	-	-	-	-	-	-

\*: optional / Yes : dosing required

## CONSUMPTION DATA

Power consumption in off-mode 0.11 W/ in left-on mode 0.11 W

Programme	Temperature (°C)	Load (kg)	Water (l)	Energy without "Rapid" (kWh)	Approx. Programme Duration ☺ (hours : minutes)	
					without "Rapid"	with "Rapid"
Cotton/Antibacterial	95	7.0	58*	2.10	2:35	2:00
Cotton	60	7.0	52	1.33	2:30	1:45
Cotton	40	7.0	52	0.80	2:25	1:30
Synthetics	60	3.0	50*	0.90	2:05	1:14
Synthetics	40	3.0	46	0.50	1:50	0:59
Synthetics	30	3.0	46	0.45	1:46	0:55
Delicate	40	1.5	50	0.55	0:45	-
Delicate	30	1.5	50	0.50	0:45	-
Daily load	40	3.0	40	0.45	1:00	-
Speed 15'	30	3.0	30	0.15	0:15	-
Wool/Handwash	40	1.0	40	0.55	0:35	-
Wool/Handwash	Cold	1.0	40	0.10	0:35	-
eCotton ◀**	60	7.0	49	0.90	4:00	-
eCotton ◀**	60	3.5	34	0.75	2:50	-
eCotton ◀**	40	3.5	34	0.65	2:30	-

Consumption values were measured in normalized conditions in compliance with standard IEC/EN 60 456. Consumption data in the home may vary with respect to the values in the table in relation to the water supply pressure and temperature, the load and the type of wash. Water and energy consumption refer to the default setting of the programmes; selecting special options or modifying spin speed or temperature will change the consumption data.

☺ The programme duration may differ from the values indicated above as it depends on the operation conditions applicable at that time (see also "Troubleshooting Guide" in your Instructions for Use).

\* To reduce the water temperature, some cold water is added at the end of the main wash cycle, before the pump drains the water out.

\*\* Standard Cotton programme and basis for Energy Label. For reasons of energy saving, the real water temperature may deviate from the declared cycle temperature.

## PREPARATION OF THE WASH CYCLE

1. Load the machine, close the drum doors and check that they are properly locked.
2. Add detergent as indicated on the front page and as described in the chapter "Detergent and Additives" in your Instructions for Use.
3. Close the lid.
4. Turn the **programme selector** to the desired programme and temperature. The lamp next to the **"Start(Pause)"** button flashes. The indication lamp of the predefined spin speed lights up. If you do not start the programme soon after having made your choice, the washing machine will switch off automatically after about a quarter of an hour. Switch on the washing machine again by turning the programme selector back to "O" and then to the desired programme.

## SELECT THE DESIRED OPTION(S)

Selecting or deselecting an option can be done at any time during the programme. The option will be applied as long as the corresponding programme phase has not been executed yet.

### "Cold wash" button

- Water is heated only up to 20°C.
- Suitable for delicate laundry items with wash temperature recommendation of max. 30°C on the care label.
- **Selectable only on the lowest temperature step of each programme.**

### "Prewash" button

- Only for heavily soiled loads (for example sand, granular dirt) . Increases the cycle time by approximately 15 min.
- Do not use liquid detergent for the main wash when activating the Prewash option.

### "Rapid" button

- Enables quicker washing by shortening the programme duration.
- Recommendable for small loads or only lightly soiled laundry.

### "Intensive rinse" button

- Add one more rinse cycle and prolong the rinse time.
- This option is particularly suitable for areas with very soft water, washing baby linen and people with skin allergies.

## "Rinse hold" button

- The laundry remains in the last rinse water without progressing to the final spin cycle to avoid creasing and prevent colours from changing.
- This option is particularly recommended for the "Synthetics", "Daily load" and "Delicates" programmes.
- It is useful if you want to postpone spinning to a later time, or if you want to drain out only.
- If you select "Rinse hold", do not leave items to soak for too long.
- As soon as the appliance stops in the rinse hold, the "Rinse hold" lamp of the sequence indicator lights up and the lamp next to the **"Start(Pause)"** button flashes.

### Terminate the "Rinse hold" option:

- Press the **"Start(Pause)"** button; the programme will terminate automatically with the final spin cycle for the present wash programme.
- If you do not wish to spin the clothes, turn the programme selector knob to the "Drain" programme and press the **"Start(Pause)"** button.

## "Variable spin" button

- Every programme has a predefined spin speed.
- Press the button to set another spin speed.
- If spin speed "0" is selected, the final spinning is cancelled but intermediate spin peaks remain during the rinse. The water is drained out only.

## PROGRAMME START

Open the tap and press the **"Start(Pause)"** button. The indication lamp next to the **"Start(Pause)"** button lights up. The programme sequence indicator shows the current programme phase, running from left to right through Wash, Rinse, Spin/Drain. When the programme phase is finished, the corresponding indication goes out.

- **Note:** If there is a power interruption or if the appliance is disconnected during the cycle, the programme will run again from the point where it was interrupted.

## "LID OPEN" INDICATION

Before starting and after end of a programme, the lamp lights to show the the lid can be opened. As long as a wash programme is running, the lid remains locked and must not be forced open. In case you have an urgent need to open it during a running programme, refer to "Cancel (Reset) a running programme before the end".

## FAILURE INDICATIONS

In case of any failures or irregularities, consult the "Troubleshooting Guide" in your Instructions for Use.

### "Water tap closed"

No or not sufficient inlet water.

### "Service" ⚙

Failure or malfunction of an electrical component.

### "Clean pump"

Waste water is not pumped out.

**Spin speed on programme sequence indicator blinks:** unbalance during spinning

## PROGRAMME END

- All the lights of the programme sequence indicator are off, and the "Lid open" indication lights up. After about a quarter of an hour, the washing machine will switch off completely to save energy.
  1. Turn the programme selector to the "O" position.
  2. Close the water tap.
  3. Open lid and drum and unload the machine.
  4. Leave the lid open for some time to allow the interior of the machine to dry.

## CHANGE PROGRAMME AND/OR OPTIONS AFTER PROGRAMME START

1. Press the **"Start(Pause)"** button to pause the programme. The light blinks.
2. Select the new programme, temperature, any options and another spin speed if you want.
3. Press the **"Start(Pause)"** button again. The new programme continues at the same position where the previous programme was interrupted. Do not add detergent for this programme.

## CANCEL A RUNNING PROGRAMME BEFORE THE END

The **"Reset"** button cancels a programme before the end. Press the **"Reset"** button for at least 3 seconds. Any existing water is drained out before the door can be opened.